

HFC-125 AND HFC-227ea CONTAINER RECHARGE KITS

Description

After a system has been discharged, the containers rupture disc valve must be rebuilt before the container can be recharged and placed back into service. The recharge kits contain all of the items required to rebuild the valve.

1 IN (25mm) Recharge Kit, P/N 85-047		
Item	Description	Part Number
1	Friction Ring	70-2060
2	Disc Assembly	70-247
3	O-Ring	02-11987
4	Valve Core-Fill Port (not shown)	02-4161
5	Reconditioning Instructions (not shown)	06-567

Note: 1 inch recharge kit is used on 5, 10, 20, 35, 60 & 100 lb. (2, 4, 8, 15, 27 & 44 L) containers.

3 IN (80mm) Recharge Kit, P/N 85-048		
Item	Description	Part Number
1	Friction Ring	70-2063
2	Disc Assembly	70-248
3	O-Ring	02-11989
4	Valve Core-Fill Port (not shown)	02-4161
5	Reconditioning Instructions (not shown)	06-567

Note: 3 inch recharge kit is used on 150, 150i, 215, 375, 650 & 1000 lb. (61, 61i, 88, 153, 267 & 423 L) containers

For a detailed procedure on recharging a Fike container w/ an Impulse Valve refer to Fike's Recharge Manual (P/N 06-290).



Approvals

Underwriters Laboratories (UL)
Underwriters Laboratories of Canada (ULC)
Factory Mutual (FM)

For exact certification listings, please reference the respective agency web site.

This document is only intended to be a guideline and is not applicable to all situations. Information is subject to Fike's full disclaimer at <http://www.fike.com/disclaimer>.